# XR-MN5

# SERVICE MANUAL

*US Model*
*Canadian Model*
*AEP Model*
*UK Model*
*E Model*
*Australian Model*

**Ver 1.1 2003. 06**

- XR-MN5 are composed of following models.
  As for the service manual, it is issued for each component model, then, please refer to them.

## COMPONENT MODEL NAME

| | XR-MN5 |
|---|---|
| COMPACT DISK DECK RECEIVER SYSTEM | CX-LMN5 |
| SPEAKER SYSTEM | SX-LMN5 |

- Abbreviation
  AUS : Australian model. TW : Taiwan model.
  CND : Canadian model. KR : Korean model.
  SP : Singapore model. TH : Thai model.

## SPECIFICATIONS

Power requirements
220 V AC, 50/60 Hz (KR)
110-240 V AC, 50/60 Hz (TH)
220-240 V AC, 50/60 Hz (SP)
240 V AC, 50/60 Hz (AUS)
230 V AC, 50/60 Hz (AEP,UK)
120 V AC, 60 Hz (US,CND,TW)
120V/220V/230-240 V AC, 50/60 Hz (E)

Power consumption
85W (EXCEPT US,CND)
80W (US,CND)

Power consumption in stanby mode
with ECO mode on:
0.26 W (EXCEPT E)
0.35W (E)
0.25 W (US,CND)
0.26 W (AEP,UK)
0.26 W(TH,KR)
0.35 W(OTHER)
with ECO mode off:
15 W (EXCEPT E)
18 W(E)
16 W (US,CND)
15 W (AEP,UK)
18 W (TH,KR)
18 W (OTHER)

Dimensions (w/h/d) Approx. 190 × 277 × 353 mm.

Mass Approx. 6.8 kg

Supplied accessories
FM antenna (1)
AM antenna (1)
Speaker cords (2)
Remote commander (1)
Batteries (2)

Specification and exeternal appearance are subject to change without notice.

## PARTS LIST

| Part No. | Description | Remark |
|---|---|---|
| | ACCESSORIES | |
| | ********** | |
| 1-477-915-11 | COMMANDER, STANDARD (RM-Z20019) | |
| 1-501-374-92 | ANTENNA, LOOP (AM) | |
| ⚠1-569-008-12 | ADAPTOR, CONVERSION 2P (E,SP,TW) | |
| 1-754-243-11 | ANTENNA (FM)(US,CND) | |
| ⚠1-770-019-15 | ADAPTOR, CONVERSION PLUG (UK) | |
| 1-793-184-22 | CONNECTOR (F TYPE ADAPTOR)(FM)(EXCEPT US,CND) | |
| 1-827-378-11 | CORD (FOR SPEAKER) | |
| 4-245-958-01 | FOOT (FOR SPEAKER) | |
| 4-246-022-01 | MANUAL, INSTRUCTION (ENGLISH,SPANISH)(US) | |
| 4-246-022-11 | MANUAL, INSTRUCTION (ENGLISH,FRENCH,POLISH, GERMAN,DUTCH,ITALIAN,SWEDISH)(AEP) | |
| 4-246-022-21 | MANUAL, INSTRUCTION (ENGLISH)(UK) | |
| 4-246-022-31 | MANUAL, INSTRUCTION (ENGLISH,SPANISH)(E) | |
| 4-246-022-41 | MANUAL, INSTRUCTION (ENGLISH,FRENCH)(CND) | |
| 4-246-022-51 | MANUAL, INSTRUCTION (ENGLISH,THAI)(TH) | |
| 4-246-022-61 | MANUAL, INSTRUCTION (ENGLISH,FRENCH,SPANISH,CHINESE)(SP) | |
| 4-246-022-71 | MANUAL, INSTRUCTION (KOREAN)(KR) | |
| 4-246-022-91 | MANUAL, INSTRUCTION (ENGLISH,CHINESE)(TW) | |
| 4-249-131-01 | COVER, BATTERY (FOR RM-Z20019) | |

| | |
|---|---|
| The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety. Replace only with part number specified. | Les composants identifiés par une marque ⚠ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié. |

# MICRO HI-FI COMPONENT SYSTEM

**9-877-182-02**
2003F16-1
© 2003.06
**Sony Corporation**
**Home Audio Company**
**Published by Sony Engineering Corporation**

http://getMANUAL.com